

Configuring Com IP Module

Press **1234** on the control panel. The below message will be displayed.



Press **7** to reach "UDL/Digi Options"



Press **Yes** ✓




Press **7** to reach "Setup modules"



Press **Yes** ✓



Press **2** to reach "Setup IP Data?"




Press **Yes** ✓



Press **Down arrow button** (↓) to select the required COM port



Insert RJ45 Cable



Note: In this example, we are configuring COM IP to COM Port 2

Press Yes ✓



Press NO (X) to edit option



Now you can enter the IP address you would like to enter & then Press Yes ✓



Now again Press Yes ✓ 2times



Press NO (X) to edit option



Now you can enter the IP address you would like to enter & then Press Yes



Press Menu (☰) three times on the control panel and then press 8 to reach "COM Port Setup"



Press Yes ✓



Press Down arrow button (↓) to select the required COM port



Press **NO (X)** to edit option



Press **NO (X)** to edit the option & **Press 4** to enable "COM IP Module"



Press **Yes** ✓



Press **Menu (☰)** three times on the control panel and then press **Yes** to logoff from your control panel

